

CRAYON FAQs AND TROUBLESHOOTING



Make sure iPad iOS is updated to version 11.4 or above

TURNING CRAYON ON/OFF

- How do I turn Logitech Crayon on/off?
 - Press the power button for 1s until the LED light turns on/fades away.



- How does Crayon connect to the iPad? Do I need to pair it with the iPad?
 - Simply power Crayon on and you are ready to go, no pairing with iPad required.
- I tried to turn on Crayon but it doesn't work when I use it on the iPad.
 - Press the power button for 1 sec to ensure that Crayon is on and has sufficient battery level:
 - Green light means the battery is sufficient and above 10%.
 - Red light means the battery is less than 10%.
 - Blinking red light means the battery life is critically low, charge Crayon immediately.
 - Check that the Crayon tip is screwed tightly on.
 - Crayon only works with iPad 6th generation (model numbers on the back of iPad A1893 or A1954). Crayon does not work with any other tablets or iPad models.
 - Make sure iPad is on and is updated with the newest iOS.

BATTERY AND CHARGING

- How do I know how much battery is left?
 - Short press the power button to check the battery level.
 - Green means the battery is sufficient and above 10%.
 - Red means the battery is less than 10%.
 - Blinking red without a battery check means the battery life is critical, it needs charging immediately.



logitech

- How do I charge Crayon?
 - Use a standard Lightning cable that you would use to charge iPad to charge Crayon.
- How often should I charge Crayon?
 - We recommend Crayon to be charged daily at the end of the school day. A full charge can support 7 hours of non-stop writing.
- Can I use crayon while charging?
 - No, Crayon will not function while charging with a Lightning cable.
- How long does it take to charge?
 - It takes 50 mins to fully charge Crayon from 0 to 100%.

PROTECTION

- My students dropped Crayon, will it still work?
 - Crayon has gone through rigorous testing and passes drop testing from up to 4 ft. If the tip of Crayon becomes damaged, new tips can be purchased as a spare part.
- The tip became damaged, how do I replace or repair it?
 - You can purchase spare tips from Logitech.
<https://www.logitech.com/en-us>
 - When you receive the replacement tips, the package will contain 10 tips, a removal tool and instructions on how to replace the tip.
- Is Crayon waterproof?
 - No, it's not waterproof.
- Will Crayon scratch or damage the iPad screen?
 - No, it will not damage the iPad screen.

COMPATIBILITY

- Can Crayon be used on other tablets (non-iPad)? What about other iPads (besides 6th Gen)?
 - Logitech Crayon only works with iPad 6th gen (model numbers on the back of iPad A1893 or A1954). Logitech Crayon will not work with non-iPad tablets, other iPad models or phones.

- Are there certain apps or programs that Crayon works with?
 - Logitech Crayon works with apps that support Apple Pencil.
 - Logitech Crayon doesn't require installation of any additional apps to work with iPad.
- Can I use multiple Crayons with one iPad?
 - Yes, you can use multiple Crayons on one iPad, but not simultaneously.
- Can I use one Crayon with multiple iPads?
 - Yes, you can move Crayon from one iPad (6th gen) to another. There is no need to pair with individual iPads, just make sure both Crayon and iPads are on.
- Can I use Crayon and Apple Pencil with the same iPad?
 - Yes, but turn off the *Bluetooth* to disable Apple Pencil if you want to use Crayon.

UPDATING FIRMWARE

- How do I update firmware on Logitech Crayon?
 - To update firmware, follow instructions [here](#).