


<p>English Features</p> <ol style="list-style-type: none"> 1. Left and right mouse buttons 2. Scroll wheel 3. Press the wheel down for middle button (function can vary by software application) 4. On/Off slider switch 5. Battery door release 6. USB Nano-receiver storage 	<p>繁體中文 功能</p> <ol style="list-style-type: none"> 1. 左右滑鼠按鈕 2. 滾輪 3. 按下滾輪可作為滑鼠中間按鈕使用 (功能會視軟體應用程式而有不同) 4. 開啟/關閉切換開關 5. 推開電池蓋 6. USB 超小型接收器儲存槽 	<p>简体中文 功能</p> <ol style="list-style-type: none"> 1. 左/右鼠标按键 2. 滚轮 3. 按下滚轮以作中键使用 (功能可能依软件应用程序而异) 4. 开启/关闭滑动开关 5. 电池盖释放 6. USB Nano 接收器存储槽 	<p>한국어 기능</p> <ol style="list-style-type: none"> 1. 왼쪽/오른쪽 마우스 버튼 2. 스크롤 휠 3. 가운데 버튼으로 휠을 누름 (이 기능은 소프트웨어 응용 프로그램에 따라 다를 수 있음) 4. 켜기/끄기 스위치 슬라이더 5. 배터리 도어 해제 6. USB 나노 수신기 스토리지
--	---	--	---



English

Help with setup: Mouse is not working

1. Is the mouse powered on?
2. Is the Nano receiver securely plugged into a USB port? Try changing USB ports.
3. If the Nano receiver is plugged into a USB hub, try plugging it directly into a USB port on your computer.
4. Check the orientation of the battery inside the mouse.
5. Try a different surface. Remove metallic objects between the mouse and the Nano receiver.
6. Try moving the Nano receiver to a USB port closer to the mouse, or use a USB extender that will allow the receiver to be placed closer to the mouse.
7. For Windows® operating systems, reconnect the mouse with the Nano receiver by launching the Connect utility from www.logitech.com/connect_utility.

繁體中文

安裝說明：滑鼠無法使用

1. 滑鼠是否已打開電源？
2. 超小型接收器是否穩固地插入到 USB 連接埠？請嘗試更換 USB 連接埠。
3. 如果超小型接收器是插在 USB 集線器上，請嘗試將其直接插入到電腦上的 USB 連接埠。
4. 檢查滑鼠內部電池的方向。
5. 嘗試不同的表面。將滑鼠和超小型接收器之間的金屬物移走。
6. 嘗試將超小型接收器移到較接近滑鼠的 USB 連接埠上，或用接收器放置在更靠近滑鼠的 USB 延長線上。
7. 如果是 Windows® 作業系統，請執行 Connect 公用程式 (可從 www.logitech.com/connect_utility 取得) 以重新連接滑鼠與超小型接收器。

简体中文

设置帮助：鼠标不工作

1. 鼠标是否已接通电源？
2. Nano 接收器是否已牢固地插入 USB 端口？尝试更换 USB 端口。
3. 如果 Nano 接收器已插入 USB 集线器，则尝试将其直接插入电脑的 USB 端口。
4. 检查鼠标内的电池方向。
5. 尝试其他表面。移除鼠标和 Nano 接收器之间的金属物体。
6. 尝试将 Nano 接收器移至离鼠标较近的 USB 端口，或使用 USB 延长器将接收器放到离鼠标较近的位置。
7. 对于 Windows® 操作系统，请启动从 www.logitech.com/connect_utility 获取的 Connect utility (“连接”实用程序)，重新连接鼠标和 Nano 接收器。

한국어

설치 도움말: 마우스가 작동되지 않을 때

1. 마우스 전원이 켜져 있습니까?
2. 나노 수신기가 USB 포트에 안정적으로 연결되어 있습니까? 다른 USB 포트에 연결해 보십시오.
3. 나노 수신기가 USB 허브에 연결되어 있으면 컴퓨터 USB 포트에 직접 연결해 보십시오.
4. 마우스 내부의 배터리 방향을 점검하십시오.
5. 다른 표면에 사용해 보십시오. 마우스와 나노 수신기 사이에 있는 금속 물체를 제거하십시오.
6. 나노 수신기를 키보드와 가까운 USB 포트로 옮기거나, USB 연장 케이블을 사용하면 수신기를 키보드와 더 가까운 곳에 배치할 수 있습니다.
7. Windows® 운영 체제의 경우 www.logitech.com/connect_utility의 연결 유틸리티를 시작하여 마우스를 나노 수신기와 다시 연결하십시오.

English

Important ergonomic information. Long periods of repetitive motion using an improperly set-up workspace, incorrect body position, and poor work habits may be associated with physical discomfort and injury to nerves, tendons, and muscles. If you feel pain, numbness, weakness, swelling, burning, cramping, or stiffness in your hands, wrists, arms, shoulders, neck, or back, see a qualified health professional. For more information, please read the Comfort Guidelines located on the Logitech web site at http://www.logitech.com/comfort, or on the Logitech Software CD.

Do not immerse product in any liquid or expose it to heat or moisture. There are no serviceable parts.

Class 1 LED products. The product contains Class 1 LED. Operating temperature between 5°C (41°F) to 40°C (104°F).

Additional compliance information. To obtain additional information about Class 1 LED, Class 1 lasers, Class 1M lasers, or other compliance-related matters, go to http://www.logitech.com/compliance, or call Logitech customer support. (Customer support telephone numbers are listed in the product documentation.)

Battery warning! Risk of explosion or personal injury if batteries are replaced by incorrect type, mutilated, or exposed to conducting materials, liquid, fire, or heat (above 54° C or 130° F). Do not use or recharge damaged rechargeable batteries. Do not mix battery types. Dispose of spent or damaged batteries according to manufacturer instructions and local laws.

Power supply warning! Caution electric shock/fire hazard! For indoor use only. Do not expose to moisture, liquid, or heat. Do not use any other power supply with your Logitech product.

Device pairing limitations. Some Unifying devices may be limited in the number of times they can be paired (connected) to a Unifying receiver. Although the number of pairings possible may vary, the minimum number of available pairings is 45.

Logitech hardware product limited warranty

Logitech warrants to the original purchaser that your Logitech hardware product shall be free from defects in material and workmanship for the period of time, identified on your product package and/or contained in the user documentation, from the date of purchase. You may also find this information by selecting your product in the Online Support section of our website at www.logitech.com/support. Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser. This warranty gives you specific legal rights, and you may also have other rights that vary under local laws.

Logitech’s entire liability and your exclusive remedy for any breach of warranty shall be, at Logitech’s option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Logitech may direct with a copy of the sales receipt and/or local warranty card. Shipping and handling charges may apply, except where prohibited by applicable law. Logitech may, at its option, use new or refurbished or used parts in good working condition to repair or replace any hardware product. Any replacement hardware product will be warranted for at least the remainder of the original warranty period.

This warranty does not cover problems or damage resulting from (1) accident, abuse, misapplication, or any unauthorized repair, modification or disassembly; (2) improper operation or maintenance, usage not in accordance with product instructions or connection to improper voltage supply; or (3) use of consumables, such as replacement batteries, not supplied by Logitech except where such restriction is prohibited by applicable law.

How to obtain warranty support. Before submitting a warranty claim, we recommend you visit the support section at www.logitech.com/support for technical assistance. Valid warranty claims are generally processed through the point of purchase during the first thirty (30) days after purchase; however, this period of time may vary depending on where you purchased your product – please check with Logitech or the retailer where you purchased your product for details. Warranty claims that cannot be processed through the point of purchase and any other product related questions should be addressed directly to Logitech. The addresses and customer service contact information for Logitech can be found in the documentation accompanying your product and on the web at www.logitech.com/support.

Limitation of liability. LOGITECH SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS, REVENUE OR DATA (WHETHER DIRECT OR INDIRECT) OR COMMERCIAL LOSS FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON YOUR PRODUCT EVEN IF LOGITECH HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Duration of implied warranties. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THIS HARDWARE PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THE APPLICABLE LIMITED WARRANTY PERIOD FOR YOUR PRODUCT. Additional Rights. Some states do not allow limitations on how long an implied warranty lasts, or allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from State to State or by country or other jurisdiction.

National Statutory Rights. Consumers have legal rights under applicable national legislation governing the sale of consumer goods. Such rights are not affected by the warranties in this Limited Warranty.

No Other Warranties. No Logitech dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

LOGITECH HARDWARE PRODUCT WARRANTY FOR AUSTRALIA AND NEW ZEALAND ONLY
Warranty provider. This warranty is provided by Logitech International SA, Rue de Sablon 2-4, CH-1110 Morges, Switzerland (telephone:+41(0)21-863-5111)

Logitech Hardware Product Limited Warranty. Logitech warrants that your Logitech hardware product shall be free from defects in material and workmanship from the date of purchase until the expiry of the period of time specified on the packaging or in the enclosed user documentation. This warranty is non-transferable and is limited to the original purchaser.

How to Obtain Warranty Support. Before submitting a warranty claim, we recommend you visit the support section at www.logitech.com for technical assistance. Valid warranty claims are generally processed through the point of purchase during the first thirty (30) days after purchase; however, this period of time may vary depending on where you purchased your product – please check with Logitech or the retailer where you purchased your product for details. Warranty claims that cannot be processed through the point of purchase and any other product related questions should be addressed directly to Logitech Australia, as follows:

Logitech Australia Computer Peripherals Pty Ltd

Level 2, 608 Liverpool Road

Strathfield South NSW 2136

Telephone: (02) 97648300

Email: generalaus@logitech.com

To make a claim under this warranty you should return the hardware to the place of purchase or to Logitech Australia with proof of original purchase such as a copy of the sales receipt or dated itemized receipt. Any expense of claiming under this warranty will be borne by you.

Your consumer rights. The benefits Logitech gives you in this hardware product warranty are in addition to and do not detract from any rights and remedies that you may have under Australian consumer protection laws. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This hardware product warranty is not intended to (1) change or exclude any statutory consumer rights that cannot be lawfully changed or excluded; or (2) limit or exclude any right you have against the person who sold the Logitech product to you if that person has breached their sale contract with you.

Logitech provides no warranty against defects beyond the rights given to you under this hardware product warranty and which are available to you under the Australian Consumer Law.

Remedies. If you make a valid claim under this warranty during the warranty period, Logitech will at its option: (1) repair or replace the product; or (2) refund the price paid.

Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. Repair of the goods may result in loss of data contained in the goods and Logitech takes no responsibility for the loss of such data. If Logitech replaces your hardware product, this warranty will be extended to cover the replacement product for the remainder of the original warranty period or thirty (30) days from the date of replacement, whichever is longer.

Exclusions. This warranty does not cover problems or damage resulting from: (1) accident, abuse, misapplication, or any unauthorized repair, modification or disassembly; (2) improper operation or maintenance, usage not in accordance with product instructions or connection to improper voltage supply; or (3) use of consumables, such as replacement batteries, not supplied by Logitech.

No Other Warranties. No Logitech dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. Repair of the goods may result in loss of data contained in the goods and Logitech takes no responsibility for the loss of such data. If Logitech replaces your hardware product, this warranty will be extended to cover the replacement product for the remainder of the original warranty period or thirty (30) days from the date of replacement, whichever is longer.

Exclusions. This warranty does not cover problems or damage resulting from: (1) accident, abuse, misapplication, or any unauthorized repair, modification or disassembly; (2) improper operation or maintenance, usage not in accordance with product instructions or connection to improper voltage supply; or (3) use of consumables, such as replacement batteries, not supplied by Logitech except where such restriction is prohibited by applicable law.

Logitech’s entire liability and your exclusive remedy for any breach of warranty shall be, at Logitech’s option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Logitech may direct with a copy of the sales receipt and/or local warranty card. Shipping and handling charges may apply, except where prohibited by applicable law. Logitech may, at its option, use new or refurbished or used parts in good working condition to repair or replace any hardware product. Any replacement hardware product will be warranted for at least the remainder of the original warranty period.

This warranty does not cover problems or damage resulting from (1) accident, abuse, misapplication, or any unauthorized repair, modification or disassembly; (2) improper operation or maintenance, usage not in accordance with product instructions or connection to improper voltage supply; or (3) use of consumables, such as replacement batteries, not supplied by Logitech except where such restriction is prohibited by applicable law.

How to obtain warranty support. Before submitting a warranty claim, we recommend you visit the support section at www.logitech.com/support for technical assistance. Valid warranty claims are generally processed through the point of purchase during the first thirty (30) days after purchase; however, this period of time may vary depending on where you purchased your product – please check with Logitech or the retailer where you purchased your product for details. Warranty claims that cannot be processed through the point of purchase and any other product related questions should be addressed directly to Logitech. The addresses and customer service contact information for Logitech can be found in the documentation accompanying your product and on the web at www.logitech.com/support.

Limitation of liability. LOGITECH SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS, REVENUE OR DATA (WHETHER DIRECT OR INDIRECT) OR COMMERCIAL LOSS FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON YOUR PRODUCT EVEN IF LOGITECH HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Duration of implied warranties. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THIS HARDWARE PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THE APPLICABLE LIMITED WARRANTY PERIOD FOR YOUR PRODUCT. Additional Rights. Some states do not allow limitations on how long an implied warranty lasts, or allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from State to State or by country or other jurisdiction.

National Statutory Rights. Consumers have legal rights under applicable national legislation governing the sale of consumer goods. Such rights are not affected by the warranties in this Limited Warranty.

No Other Warranties. No Logitech dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

LOGITECH HARDWARE PRODUCT WARRANTY FOR AUSTRALIA AND NEW ZEALAND ONLY
Warranty provider. This warranty is provided by Logitech International SA, Rue de Sablon 2-4, CH-1110 Morges, Switzerland (telephone:+41(0)21-863-5111)

Logitech Hardware Product Limited Warranty. Logitech warrants that your Logitech hardware product shall be free from defects in material and workmanship from the date of purchase until the expiry of the period of time specified on the packaging or in the enclosed user documentation. This warranty is non-transferable and is limited to the original purchaser.

How to Obtain Warranty Support. Before submitting a warranty claim, we recommend you visit the support section at www.logitech.com for technical assistance. Valid warranty claims are generally processed through the point of purchase during the first thirty (30) days after purchase; however, this period of time may vary depending on where you purchased your product – please check with Logitech or the retailer where you purchased your product for details. Warranty claims that cannot be processed through the point of purchase and any other product related questions should be addressed directly to Logitech Australia, as follows:

責任限制。 羅技對於因為違反任何產品明示或默示保固責任所招致的任何特殊、間接、意外或衍生性損壞等，其中包括（但不限於）直接或間接的利益、收入或資料損失或商業損失，不承擔任何責任，即使羅技已被事先告知這類損壞的可能性也是如此。

默示擔保責任的期限。 除法律規定禁止之範圍以外，任何默示擔保責任或對此硬體產品的適售性或某特定用途適用性，是以以該產品適用之有限保固期為準。其他權利。部分州（省）不允許限制默示擔保責任持續的期限，或不允許意外或衍生性損壞的排除或限制，因此上述限制或排除可能不適用。您除了享有本保固中的特定法律權利，也可能會因州（省）際之間或依據國家或其他司法管轄領域而享有其他不同的權利。

國家法律權利。 在販售消費性商品之國家的法律約束下，消費者得享有法律權利。這些權利不受此有限保固中的擔保責任影響。

無其他保固。 羅技經銷商、代理商或員工都沒有權利對此書面提供之保固服務進行任何修改、展延或附加。

Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. Repair of the goods may result in loss of data contained in the goods and Logitech takes no responsibility for the loss of such data. If Logitech replaces your hardware product, this warranty will be extended to cover the replacement product for the remainder of the original warranty period or thirty (30) days from the date of replacement, whichever is longer.

简体中文

人体工程学方面的重要信息。 长时间重复单一动作、工作环境中设备安置不当、身体姿势不正确以及不良的工作习惯，都可能引起身体不适，从而对神经、肌腱造成损伤。如果您的手部、手腕、胳膊、肩部、颈部或背部感到疼痛、麻痺、酸软无力、肿胀、灼痛、抽筋或僵硬等，请向合格的专业保健人士咨询。有关详细信息，请阅读罗技网站 http://www.logitech.com/comfort 上或罗技软件光盘中的“舒适指南”。请勿将产品浸入任何液体中或暴露于热量或潮湿环境中。没有可供使用者自行维修的零件。

1 类 LED 产品。 本产品包含 1 类 LED。操作温度为 5°C (41°F) 到 40°C (104°F)。

有关合规性的更多信息。 要获得有关 1 类 LED、1 类激光、1M 类激光或其他符合性相关事宜的更多信息，请转至 http://www.logitech.com/compliance 或致电罗技客户支持。（产品文档中列出了客户支持电话号码。）

电池警告！ 如果更换的电池的类型不正确、切开电池或使之暴露在导电材料、液体、火或热量（超过 54°C 或 130°F）等环境中，则可能导致爆炸或造成人身伤害。请勿使用已损坏的可充电电池或对其充电。请勿混用不同类型的电池。应根据制造商说明和当地法律的要求弃置废弃或已损坏的电池。

电源警告！ 注意电击！火灾危险！仅限室内使用。不要使之暴露于潮湿、液体或热敏环境中。请勿将任何其它电源用于您的罗技产品。设备配对限制。某些 Unifying 设备与 Unifying 接收器进行配对（连接）的次数可能有限。虽然配对的个数可能有所不同，但有效配对的最少个数为 45。

罗技硬件产品有限保修

罗技向原始购买者保证，罗技硬件产品自购买之日起，在产品包装上和/或用户文档中明确的期限内不会出现材料和工艺方面的缺陷。您还可以通过在 www.logitech.com/support 网站的在线支持部分选择所购产品来获取相关信息。除非适用的法律禁止，否则本保修不可转让，且仅限于原始购买者。本保修赋予您特定的法律权利，而依据当地法律，您可能还享有其它不同的权利。

在产品期内如果出现质量问题，罗技对您负有全部责任以及您所享有的全部补偿权利将限于由罗技选择维修或更换硬件，前提是您将硬件退还至购买地点或罗技指定的其它地点，并附上销售收据或注明日期并带有详细部件的收据副本。您还应承担运输费和手续费（适用法律禁止的情形除外）。罗技可以选择使用新的、修理过或使用过的可以正常工作零件来修复或更换任何硬件产品。更换后的硬件产品的保修期为原保修期的剩余期限或三十（30）天（以较长者为准），或者您所在可法辖区所适用的任何其它期限。

本保修不包含因以下情况导致的故障或损坏：(1) 意外事故、滥用、使用不当或任何擅自维修、改动或拆卸；(2) 不正确的操作或维护、不依照产品说明进行使用，或连接到不适当的电源；或者 (3) 使用非罗技提供的消耗品，如替换电池等，但适用法律禁止此类限制的情况除外。

如何获得质保支持。 在提交质保要求之前，我们建议您访问 www.logitech.com/support 上的支持部分，了解技术支持方面的信息。在购买后的 30 天之内，有效的保修申请要由购买点处理，但这一时间期限会随购买地点的不同而有所不同- 详细信息，请联络罗技或向您出售产品的零售商。如果不能在购买地点处理保修申请，或者与产品有关的任何其他疑问，请直接与罗技联系解决。可以从产品随附的文档或网站 www.logitech.com/support 上找到罗技的地址和客户服务联系信息。

有限责任。 罗技对于任何特殊、间接、偶发或继发性损害均不承担任何责任，包括但不限于利益损失、收入损失或数据丢失（无论是直接还是间接）或由于违反本产品的任何明示或暗示质保条款而导致的商业损失，即使罗技事前已知晓此类损害的可能性也是如此。

暗示质保限制。 除适用法律禁止的情形之外，任何与本硬件产品有关的适销性或特定用途适用性的暗示质保或条件均不得超过适用于本产品的有限质保期所规定的期限。其它权利。某些国家不允许限制暗示担保责任的持续期限，也不允许排除或限制伴随或因而生出的损害赔偿責任，因此以上限制或排除条款可能对您不适用。本有限质保赋予您特定的法律权利，您享有的其它权利视州、国家/地区或可法辖区不同而有所不同。

国家法定权利。 消费者享有针对消费品销售的适用国家法规所规定的合法权利。此类权利不受“有限质保条款”保修条款的影响。

无其它质保。 任何罗技经销商、代理商或雇员均无权对本质保责任进行任何更改、延伸或增补。

한국어

인체공학적 중요 정보. 잘못된 자세, 잘못된 몸의 자세, 잘못된 작업 습관을 오랫동안 반복할 경우 신체적 불편과 신경, 팔꿈, 근육 부상으로 이어질 수 있습니다. 손이나 손목, 팔, 어깨, 목 또는 등에 통증이나 마비, 무력감, 부종, 발열, 경련, 경직 등의 증상이 느껴지면 전문의의 진찰을 받으십시오.
관련 내용은 Logitech 웹 사이트 (<http://www.logitech.com/comfort>) 또는 Logitech 소프트웨어 CD 의 Comfort Guidelines 를 참조하십시오. 제품을 액체에 담그거나 열 또는 습기에 노출시키지 마십시오. 수리할 수 있는 부분이 없습니다.

클래스 1 LED 제품. 이 제품에는 클래스 1 LED가 포함되어 있습니다. 작동 온도는 5°C - 40°C입니다.

추가 규정 준수 정보. 클래스 1 LED, 클래스 1 레이저, 클래스 1M 레이저 또는 기타 규정 준수에 관련된 내용은 <http://www.logitech.com/compliance> 를 참조하거나 Logitech 고객 지원 센터에 문의하십시오. (고객 지원 센터 전화 번호는 홈페이지를 참고하십시오.)

배터리 경고! 잘못된 유형의 배터리를 교체하거나, 배터리를 분해하거나, 도재/액체/화기/열기 (54°C 이상)에 배터리가 노출되는 경우 폭발 또는 부상을 입을 위험이 있습니다. 손상된 충전식 배터리는 사용하거나 재충전하지 마십시오. 서로 다른 유형의 배터리를 함께 사용하지 마십시오. 더 얇거나 손상된 배터리는 제조업체의 지침 및 해당 지역의 법규에 따라 폐기해야 합니다.

전원 공급 장치 경고! 감전/화재 위험에 주의하십시오! 실내에서만 사용하십시오. 습기/액체/열기에 노출하지 마십시오. Logitech 제품이 타사의 전원 공급 장치를 사용하지 마십시오.

장치 페어링 제한. Unifying 장치 중 일부는 Unifying 리시버와 페어링 (연결) 가능한 횟수가 제한될 수 있습니다. 페어링 가능 횟수는 장치마다 다르지만 최소 45 회 이상입니다.

Logitech 하드웨어 제품 제한 보증

Logitech 은 원 구입자에게 구입하신 Logitech 하드웨어 제품에 대해 재질 및 제작 기술상의 결함이 없음을 구입일로부터 제품 패키지에 명시되고/또는 사용 설명서에 제시된 기간 동안 보증합니다. 이 정보는 또한 Logitech 웹 사이트의 온라인 지원 섹션 (www.logitech.com/support) 에서 제품을 선택하여 확인할 수 있습니다. 법적으로 금지된 경우를 제외하고, 이 보증은 양도할 수 없으며 구입 당사자에만 적용됩니다. 이 보증은 귀하에게 특정 법적 권리를 부여하며, 귀하는 관할 지역의 법에 따른 기타 권리를 보유할 수도 있습니다.

보증 위반에 대한 Logitech 의 모든 책임과 사용자의 유일한 구제 방법은 하드웨어를 보내고 구매 품목이 인쇄된 영수증 사본과 함께 구입처 또는 Logitech 에서 지정한 장소로 반환하는 경우, Logitech 의 선택에 따라 해당 하드웨어를 수리 또는 교체할 수 있는 것입니다. 법적으로 금지된 경우를 제외하고, 배송 및 취급 수수료가 적용될 수 있습니다. 하드웨어 제품 수리 및 교체 시 Logitech 은 제대로 작동하는 상태의 신규 부품이나 인쇄 부품 또는 증교 부품을 지체 판단에 따라 사용할 수 있습니다. 교체 하드웨어 제품의 보증 기간은 원래 보증 기간의 남은 시일과 30 일 중 긴 기간 또는 해당 관할 구역에서 적용되는 추가 기간으로 정합니다.

(1) 사고, 남용, 오용 또는 기타 무단 수리, 변경이나 해체 (2) 올바른 지 않은 작동이나 보수, 제품 설명서를 따르지 않은 사용 또는 잘못된 전압 연결 (3) Logitech 에서 공급하지 않은 소모품 (예: 교체 배터리) 사용 등으로 발생한 문제나 피해에 대해서는 이 보증이 적용되지 않습니다. 단, 법적으로 그러한 제한이 금지된 경우는 제외합니다.

보증 지원 이용 방법. 보증 청구에 앞서 www.logitech.com/support 의 지원 섹션에서 기술 지원 사항을 확인할하는 것이 좋습니다. 일반적으로 유효한 보증 청구는 구입일로부터 최초 30일간 구입처에서 처리합니다. 그러나 이 기간은 제품 구입처에 따라 달라질 수 있습니다. 자세한 내용은 Logitech 또는 제품 구입처에 문의하십시오. 구입처에서 처리할 수 없는 보증 청구나 그 밖의 제품 관련 사항은 Logitech 으로 직접 문의하십시오. Logitech 고객 서비스 센터 주소 및 연락처는 제품과 함께 제공된 설명서 및 웹 사이트 (www.logitech.com/support) 에서 확인할 수 있습니다.

책임 제한. LOGITECH 은 해당 제품에 대한 명시적 또는 묵시적 보증 위반과 관련하여 이익, 매출 또는 데이터의 (직간접적) 손실, 금전적 손실을 비롯하여 어떠한 특수한, 간접적, 결과적 또는 우발적 손해에 대해 그와 같은 손해의 가능성을 사전에 알고 있던 경우를 포함하여 어떠한 경우에도 책임을 지지 않습니다.



묵시적 보증 기간. 법적으로 금지된 범위를 제외하고, 이 하드웨어의 시장성 또는 특정 목적에의 적합성에 대한 묵시적 보증이나 조건의 기간은 해당 제품에 적용된 제한적 보증 기간으로 한정합니다. 기타 권리. 일부 관할 지역에서는 묵시적 보증 기간에 대한 제한을 허용하지 않거나 결과적 또는 우발적 손해의 배제 또는 제한을 허용하지 않으며, 그러한 경우 위와 같은 제한 또는 배제는 적용되지 않습니다. 이 보증은 귀하에게 특정 법적 권리를 부여하며, 귀하는 주, 국가, 관할 지역에 따라 다른 기타 권리를 보유할 수도 있습니다.

국가별 법적 권리. 소비자들은 소비자 상품 판매에 관한 국가별 법령에 따라 법적 권리를 가집니다. 그러한 권리는 이 제한적 보증에서 정한 보증의 영향을 받지 않습니다.

기타 보증 금지. 어떠한 Logitech 딜러, 대리인 또는 직원도 이 보증 내용을 수정, 연장 또는 추가할 권한이 없습니다.

																																																	
产品中有毒有害物质或元素名称及含量 根据中国 <<电子信息产品污染控制管理办法>>																																																	
<table><thead><tr><th>限制物质 Monoc</th><th colspan="6">有毒有害物质或元素 Toxic or Hazardous Substances and Elements</th></tr><tr><th>部件名称 Parts Name</th><th>铅 (Pb)</th><th>汞 (Hg)</th><th>六价铬 (Cr(VI))</th><th>多溴联苯 (PBB)</th><th>多溴二苯醚 (PBDE)</th><th></th></tr></thead><tbody><tr><td>电源线/电缆 Cable/Adaptor</td><td>X</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr><tr><td>电源线附件 PWA</td><td>X</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr><tr><td>塑料外壳 Plastic enclosure</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr><tr><td>塑料部件 Plastic parts</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr><tr><td>金属部件 Metal parts</td><td>X</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr></tbody></table> <p>(X = 表示该有害物质在部件材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求以下。 O = 表示该有害物质至少在部件体的某一均质材料中的含量超过 SJ/T 11363-2006 标准规定的限量要求。)</p> <p>注：环保使用期限的参考标准：取決于产品正常工作温度和湿度等条件。</p>	限制物质 Monoc	有毒有害物质或元素 Toxic or Hazardous Substances and Elements						部件名称 Parts Name	铅 (Pb)	汞 (Hg)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)		电源线/电缆 Cable/Adaptor	X	O	O	O	O	O	电源线附件 PWA	X	O	O	O	O	O	塑料外壳 Plastic enclosure	O	O	O	O	O	O	塑料部件 Plastic parts	O	O	O	O	O	O	金属部件 Metal parts	X	O	O	O	O	O
限制物质 Monoc	有毒有害物质或元素 Toxic or Hazardous Substances and Elements																																																
部件名称 Parts Name	铅 (Pb)	汞 (Hg)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)																																												
电源线/电缆 Cable/Adaptor	X	O	O	O	O	O																																											
电源线附件 PWA	X	O	O	O	O	O																																											
塑料外壳 Plastic enclosure	O	O	O	O	O	O																																											
塑料部件 Plastic parts	O	O	O	O	O	O																																											
金属部件 Metal parts	X	O	O	O	O	O																																											
																																																	

© 2012 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

																																																	
产品中有毒有害物质或元素名称及含量 根据中国 <<电子信息产品污染控制管理办法>>																																																	
<table><thead><tr><th>接受物质 Receiver</th><th colspan="6">有毒有害物质或元素 Toxic or Hazardous Substances and Elements</th></tr><tr><th>部件名称 Parts Name</th><th>铅 (Pb)</th><th>汞 (Hg)</th><th>六价铬 (Cr(VI))</th><th>多溴联苯 (PBB)</th><th>多溴二苯醚 (PBDE)</th><th></th></tr></thead><tbody><tr><td>电源线/电缆 Cable/Adaptor</td><td>X</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr><tr><td>电源线附件 PWA</td><td>X</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr><tr><td>塑料部件 Plastic parts</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr><tr><td>橡胶部件 Rubber parts</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr><tr><td>金属部件 Metal parts</td><td>X</td><td>O</td><td>O</td><td>O</td><td>O</td><td>O</td></tr></tbody></table> <p>(X = 表示该有害物质在部件材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求以下。 O = 表示该有害物质至少在部件体的某一均质材料中的含量超过 SJ/T 11363-2006 标准规定的限量要求。)</p> <p>注：环保使用期限的参考标准：取決于产品正常工作温度和湿度等条件。</p>	接受物质 Receiver	有毒有害物质或元素 Toxic or Hazardous Substances and Elements						部件名称 Parts Name	铅 (Pb)	汞 (Hg)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)		电源线/电缆 Cable/Adaptor	X	O	O	O	O	O	电源线附件 PWA	X	O	O	O	O	O	塑料部件 Plastic parts	O	O	O	O	O	O	橡胶部件 Rubber parts	O	O	O	O	O	O	金属部件 Metal parts	X	O	O	O	O	O
接受物质 Receiver	有毒有害物质或元素 Toxic or Hazardous Substances and Elements																																																
部件名称 Parts Name	铅 (Pb)	汞 (Hg)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)																																												
电源线/电缆 Cable/Adaptor	X	O	O	O	O	O																																											
电源线附件 PWA	X	O	O	O	O	O																																											
塑料部件 Plastic parts	O	O	O	O	O	O																																											
橡胶部件 Rubber parts	O	O	O	O	O	O																																											
金属部件 Metal parts	X	O	O	O	O	O																																											
																																																	

© 2012 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.